Krome Soundtrack Loading Instructions

After you download, unzip the “Krome Soundtrack” file. There is one file included in the folder: NEPRO3.PCG

Remove the file from the Krome folder and save it to the “Top Level” of your Smart Media Card.

Do not save the actual folder titled Kid Nepro Soundtrack. Only the NEPRO3.PCG file inside the folder.
After you have saved the file to the card, remove the card from your computer and insert into the card slot in the rear of Krome.

Power up your Krome with the card inserted and follow these steps to load:

Choose Media/LOAD
Choose NEPRO3.PCG
Choose LOAD

Programs load into USER F bank
Combis load into USER D bank

PCG data will remain in the Krome Memory and does not need to be loaded each time you power up.

Any questions or problems, just e-mail us at: support@kidnepro.com