



Thank you for your purchase of EXs 182 - Electric Guitars 3

Please read the following before loading your new sounds

Kronos Electric Guitars 3 requires that you have Kronos OS Version 3.1 or later installed

You can download at: – <https://www.korg.com/us/support/download/product/0/424/>

PCG Programs are set to load in USER-DD - Combi data is set up to load into your USER-D Bank

If you would like to load the sounds into another bank, follow the instructions at this link:

<http://www.kidnepro.com/blog/korg-kronos-tutorial-how-to-move-sound-banks/>

How To Load Data

- 1- Insert your USB drive into one of the USB slots in the back of Kronos.
- 2- Choose "Disk" and select your USB drive.
- 3- Find the EXs 182 folder on your USB drive choose "Open".
- 4- Choose "EXs182.exsins" and "Install". Choose "OK".
- 5- Data will install to your Kronos Internal hard disk. Wait until you receive the "Installation Successful" box and choose "OK".
- 6- Switch from your USB drive to Internal HD. Find the Kid Nepro" folder

and choose "Open".

7- Choose "EXs182 Electric Guitars 3" folder and choose "Open". Choose EXs182.KSC and choose "Load".

8- Highlight Box "Load EXs182.PCG too". Select KSC Allocation: "Clear Sampling Mode Data" - Load Method "KSC Settings". Choose "OK".

9- Data will load in a few seconds into Memory. Do not touch anything while data is loading.

Programs & Combis require that factory EXs Drum samples be loaded and all factory sounds be loaded. If the samples are not found, you will receive the "samples not loaded" message when accessing program or combi data.

Remember that while the PCG file stays in memory until you load in something else, you must load in the KSC file each time you power up your Kronos. To make things easier just save our KSC to the Kronos internal hard disk and set the KSC file to autoload when Kronos starts up. More info on how to set the autoload at: <https://www.kidnepro.com/blog/how-to-set-up-auto-load-on-korg-kronos/>

Programs & Combis require that factory EXs Drum samples be loaded and all factory sounds be loaded. If the samples are not found, you will receive the "samples not loaded" message when accessing program or combi data.

If you have any questions please contact us: **support@kidnepro.com**

KRONOS Editor 3

KORG KRONOS SET LIST COMBI **PROG** SEQ GLOBAL

PROGRAM USER-DD Bank →R ←T ALL

0 TC Clean E-Guitar	32 Chung Loop 1	64 Init Program	96 Init Program
1 TC Overdrive Lead	33 Chung Loop 2	65 Init Program	97 Init Program
2 TC Fat 4ths Lead	34 Chung Loop 3	66 Init Program	98 Init Program
3 TC Clean Octave Mix	35 Chung Loop 4	67 Init Program	99 Init Program
4 TC Harmonics	36 Chung Loop 5	68 Init Program	100 Init Program
5 TC Harmonics 2	37 Chung Loop 6	69 Init Program	101 Init Program
6 TC Harmonic 4ths	38 Chung Loop 7	70 Init Program	102 Init Program
7 TC Clean Harmonic Vel	39 Rock Loop 1	71 Init Program	103 Init Program
8 TC Fingered	40 Rock Loop 2	72 Init Program	104 Init Program
9 TC Muted	41 Rock Loop 3	73 Init Program	105 Init Program
10 TC Mute-Clean Velocity	42 Rock Loop 4	74 Init Program	106 Init Program
11 TC Mute-Clean Split	43 Power Loop 1	75 Init Program	107 Init Program
12 TC Mute-Harmonic Split	44 Power Loop 2	76 Init Program	108 Init Program
13 TC Hard Rock Lead	45 Power Loop 3	77 Init Program	109 Init Program
14 TC Hits & Bits	46 Power Loop 4	78 Init Program	110 Init Program
15 TC Hits & Splits	47 Power Loop 5	79 Init Program	111 Init Program
16 TC Licks & Riffs	48 Init Program	80 Init Program	112 Init Program
17 TC Detuned Lead	49 Init Program	81 Init Program	113 Init Program
18 TC Subtle Overdrive	50 Init Program	82 Init Program	114 Init Program
19 TC Big Feedback Lead	51 Init Program	83 Init Program	115 Init Program
20 TC Clean & Riffs Split	52 Init Program	84 Init Program	116 Init Program
21 TC With FX-1	53 Init Program	85 Init Program	117 Init Program
22 TC Mondo Lead	54 Init Program	86 Init Program	118 Init Program
23 TC Big Splits	55 Init Program	87 Init Program	119 Init Program
24 TC Power Chords	56 Init Program	88 Init Program	120 Init Program
25 TC Power Chords 2	57 Init Program	89 Init Program	121 Init Program
26 TC Power Chords Split	58 Init Program	90 Init Program	122 Init Program
27 TC Power Chords 3	59 Init Program	91 Init Program	123 Init Program
28 TC Power Chords 4	60 Init Program	92 Init Program	124 Init Program
29 TC Funk Bits	61 Init Program	93 Init Program	125 Init Program
30 TC Muted 2	62 Init Program	94 Init Program	126 Init Program
31 TC Got The Power	63 Init Program	95 Init Program	127 Init Program

INT-A	INT-B	INT-C	INT-D	INT-E	INT-F	INT-G (0) ▾
USER-A	USER-B	USER-C	USER-D	USER-E	USER-F	USER-G
USER-AA	USER-BB	USER-CC	USER-DD	USER-EE	USER-FF	USER-GG

KRONOS Editor 3

KORG KRONOS SET LIST COMBI PROG SEQ GLOBAL

COMBI USER-D Bank →R ←T ALL

0 E-Guitars V3	32 Init Combi	64 Init Combi	96 Init Combi
1 Smooth TC Split	33 Init Combi	65 Init Combi	97 Init Combi
2 Hits & Riffs	34 Init Combi	66 Init Combi	98 Init Combi
3 3 Way Split & Riffs	35 Init Combi	67 Init Combi	99 Init Combi
4 Big Bad Guitarzan Eb LP	36 Init Combi	68 Init Combi	100 Init Combi
5 Rock My World Eb Loop	37 Init Combi	69 Init Combi	101 Init Combi
6 Rock The House Eb Loop	38 Init Combi	70 Init Combi	102 Init Combi
7 Brooklyn Street Mix	39 Init Combi	71 Init Combi	103 Init Combi
8 Muted Rock Splits	40 Init Combi	72 Init Combi	104 Init Combi
9 Harmonic Clean Split	41 Init Combi	73 Init Combi	105 Init Combi
10 Purple People's AX	42 Init Combi	74 Init Combi	106 Init Combi
11 AX Mr Bigly	43 Init Combi	75 Init Combi	107 Init Combi
12 Big Bad Split	44 Init Combi	76 Init Combi	108 Init Combi
13 Dance Mix Split	45 Init Combi	77 Init Combi	109 Init Combi
14 Power Finger Split	46 Init Combi	78 Init Combi	110 Init Combi
15 Hard Core Split	47 Init Combi	79 Init Combi	111 Init Combi
16 Init Combi	48 Init Combi	80 Init Combi	112 Init Combi
17 Init Combi	49 Init Combi	81 Init Combi	113 Init Combi
18 Init Combi	50 Init Combi	82 Init Combi	114 Init Combi
19 Init Combi	51 Init Combi	83 Init Combi	115 Init Combi
20 Init Combi	52 Init Combi	84 Init Combi	116 Init Combi
21 Init Combi	53 Init Combi	85 Init Combi	117 Init Combi
22 Init Combi	54 Init Combi	86 Init Combi	118 Init Combi
23 Init Combi	55 Init Combi	87 Init Combi	119 Init Combi
24 Init Combi	56 Init Combi	88 Init Combi	120 Init Combi
25 Init Combi	57 Init Combi	89 Init Combi	121 Init Combi
26 Init Combi	58 Init Combi	90 Init Combi	122 Init Combi
27 Init Combi	59 Init Combi	91 Init Combi	123 Init Combi
28 Init Combi	60 Init Combi	92 Init Combi	124 Init Combi
29 Init Combi	61 Init Combi	93 Init Combi	125 Init Combi
30 Init Combi	62 Init Combi	94 Init Combi	126 Init Combi
31 Init Combi	63 Init Combi	95 Init Combi	127 Init Combi

INT-A	INT-B	INT-C	INT-D	INT-E	INT-F	INT-G
USER-A	USER-B	USER-C	USER-D	USER-E	USER-F	USER-G