



© 2012-2015 by SOP - All Rights Reserved
This document is protected by EU copyright and other intellectual property laws and may not be reproduced, rewritten, distributed, re-disseminated, transmitted, displayed, published or broadcast, directly or indirectly, in any medium without the prior written permission of SoP.

Sounds of Planet would like to thank you for purchase of sound set called EXs110: Protein No.1 for Kronos.

EXs110: Protein No.1 includes 128 new programs with stereo and mono Multisamples and 32 Combis.

Applied sampling technology allowed to obtain new excellent patches, which in combination with Kronos' HD-1 engine sound really superbly and very inspiring.

128 programs from Protein No. 1 set provide the sounds in such musical categories as: – MotionSynth, SlowSynth, Vocal, FastSynth, Bass, Short Decay, Lead, Woodwind, Bells, Sfx.

Controllers programmed to each patch (joystick, 2 switches over joystick, ribbon and Vector Joystick) have significant impact on sound of all 128 programs. New set is an effect of a dozen or so months of work with samples and Kronos programming. These new sounds will be very useful in various musical genres, but first of all will allow you to enter a new sound space. EXs110: Protein No.1 – a sound set really necessary to get the best out of your favourite Korg machine.

Make a copy of all own files in the instrument performing SAVE ALL function- see manual KRONOS_Quick_Starts or KRONOS_Param_Guide.

The following instructions are copied from the Kronos Parameter Guide for your convenience:
To install an EXs:

1. If you downloaded the EXs data, un - zip the downloaded file. Un - zipping the archive will result in a folder containing several different files. Note: Depending on your browser settings, the downloaded file may be unzipped automatically. One of the files in the resulting folder has a name which ends with “tar.gz.” Please do not un - zip this tar.gz file.
2. Copy the un - zipped folder to a USB storage device.
3. Safely disconnect the USB storage device from your computer.
4. Connect the USB storage device to the KRONOS.
5. Go to the Disk Utility page.
6. Using the Drive Select menu at the bottom of the page, select the USB storage device. You may need to wait a few seconds after connecting the device before it is recognized.
7. Open the folder containing the EXs data from step 2.
8. Select the file whose name ends in .exsins. The “exsins” suffix stands for “EXS INStaller.” For instance, an installer file might be named “EXs111.exsins.” When an .exsins file is selected, the Load button changes to read Install. Only one EXs can be installed at a time. If Multiple Select is On, Install will be disabled.
9. Select Install EXs from the menu, or press the Install button. The system will check to confirm that the installation files are valid, and that there is sufficient space on the SSD to install the EXs. Next, a dialog box will appear:
Found installer for: [EXs name]
Space required: [nnn] MB
SSD1: [disk name] [nnn] GB available
10. Press Install to continue with the installation, or press Cancel to stop without installing. An “are you sure?” message will appear to confirm the installation.
11. Press OK to continue with the installation, or press Cancel to stop without installing. The installation will then begin. This may take a while; a progress bar shows the

installation as it proceeds. Next, the newly installed files will be verified. After the verification has completed successfully, the progress bar will disappear, and the installation is complete. The EXs sample data itself is installed on an invisible, protected part of the disk. To use the EXs, you'll load its associated files (.KSC, .PCG etc.); for the location of these files, see the documentation of the specific EXs.

Using the newly installed EXs

To use the new EXs:

1. Load the newly installed .PCG and .KSC files. Make sure to back up any sounds before over - writing them in memory. By default, Earth programs will load to the U-EE bank. For more information, see the following sections in the Kronos Parameter Guide:

Global "0-3: KSC Auto - Load"

Global "0-4: Sample Management"

Disk mode menu command "Load .PCG"

Disk mode menu command "Load .KSC"

Authorization

If an authorization code is required, the EXs will work in demo mode, fading in and out, until the code is purchased and entered into the KRONOS. For more information, see "Global P6: Options Info".

New programs are installed in bank U-DD. Program & Multisample List:

No Program	Patch Name	Category	No Program	Patch Name	Category
U-DD000	Glass World	MotionSynth	U-DD032	Khor	SlowSynth
U-DD001	Sycorax	MotionSynth	U-DD033	Tytania	SlowSynth
U-DD002	Walking pad	MotionSynth	U-DD034	Kalba	SlowSynth
U-DD003	Open the door	MotionSynth	U-DD035	Hydrogen	SlowSynth
U-DD004	Singing WAVE	MotionSynth	U-DD036	Charon	SlowSynth
U-DD005	Rea	MotionSynth	U-DD037	Symetry	SlowSynth
U-DD006	Larissa	MotionSynth	U-DD038	White PAD	SlowSynth
U-DD007	Westa Pad	MotionSynth	U-DD039	Carme	SlowSynth
U-DD008	Faraon Pad	MotionSynth	U-DD040	Cimeria	SlowSynth
U-DD009	BlackAndWhite	MotionSynth	U-DD041	Pallas	SlowSynth
U-DD010	Reflections	MotionSynth	U-DD042	Analog Pad	SlowSynth
U-DD011	Glee	MotionSynth	U-DD043	Secret	SlowSynth
U-DD012	Astraea	MotionSynth	U-DD044	Meiousei	SlowSynth
U-DD013	Island Lead	MotionSynth	U-DD045	Yellow Light	SlowSynth
U-DD014	Elara	MotionSynth	U-DD046	Argaron	SlowSynth
U-DD015	Pulse Wall	MotionSynth	U-DD047	Kaliban Filter	SlowSynth
U-DD016	Aureola	MotionSynth	U-DD048	Motion Voco	Vocal
U-DD017	Substance	MotionSynth	U-DD049	Grian Vocal	Vocal
U-DD018	Fiala	MotionSynth	U-DD050	Sad Choir	Vocal
U-DD019	Metist MotionSynth	MotionSynth	U-DD051	Classical Choir SoP	Vocal
U-DD020	Galaxy PAD JS(+)	MotionSynth	U-DD052	East Voices	Vocal
U-DD021	Shaipur	MotionSynth	U-DD053	Dooog Voices	Vocal
U-DD022	Water Window	MotionSynth	U-DD054	SoP Stereo Voices	Vocal
U-DD023	Retrospection	MotionSynth	U-DD055	JAPAN SYNTH	FastSynth
U-DD024	Space sea	MotionSynth	U-DD056	JOWISZ SYNTH	FastSynth
U-DD025	Nereida	MotionSynth	U-DD057	SZUSS TONE	FastSynth
U-DD026	Amaltea	MotionSynth	U-DD058	POLY SYNTH	FastSynth
U-DD027	HIT Vocal AND Pad	MotionSynth	U-DD059	TERRA SYNTH	FastSynth
U-DD028	Chemistry	MotionSynth	U-DD060	IAU SYNTH	FastSynth
U-DD029	DARK BUTTERFLIES	MotionSynth	U-DD061	CLASIC SYNTH	FastSynth
U-DD030	PAD SEQ FX	MotionSynth	U-DD062	Trinculo Key	FastSynth
U-DD031	FRACTAL VOCAL	MotionSynth	U-DD063	SUKRA DANCE SYNTH	FastSynth

No Program	Patch Name	Category	No Program	Patch Name	Category
U-DD064	VARUN SYNTH	FastSynth	U-DD096	FIRE LEAD	LEAD
U-DD065	POLY ARP	FastSynth	U-DD097	FLY	LEAD
U-DD066	LOGOTYP BASS	BASS	U-DD098	FX Lead	LEAD
U-DD067	BASS REG	BASS	U-DD099	HARMONIC LEAD	LEAD
U-DD068	BASS TECH 1	BASS	U-DD100	LUNA Lead	LEAD
U-DD069	BASS TECH 2	BASS	U-DD101	GIOVE Lead	LEAD
U-DD070	BASS TECH 3	BASS	U-DD102	KUU LEAD	LEAD
U-DD071	POLY BASS	BASS	U-DD103	Saturn Lead	LEAD
U-DD072	FUUN BASS	BASS	U-DD104	Lead and VOICE	LEAD
U-DD073	BOMBER Bass	BASS	U-DD105	SUKRA LEAD	LEAD
U-DD074	BASS TECH 4	BASS	U-DD106	Lead HART	LEAD
U-DD075	STICK BASS	BASS	U-DD107	JEEGOO Lead	LEAD
U-DD076	BASS TUBE	BASS	U-DD108	CYBER HAND	LEAD
U-DD077	ARP 1980	Short Decay	U-DD109	ELECTRON LEAD	LEAD
U-DD078	ARP DAL	Short Decay	U-DD110	DAL LEAD	LEAD
U-DD079	PANDORA ARP	Short Decay	U-DD111	LED Lead	LEAD
U-DD080	ARP VARUN	Short Decay	U-DD112	JET Lead SW1	LEAD
U-DD081	GURU ARP RANDOM	Short Decay	U-DD113	NAHEED LEAD	LEAD
U-DD082	ARP URAN	Short Decay	U-DD114	SWISS LEAD	LEAD
U-DD083	ARP KASEI	Short Decay	U-DD115	PROTON LEAD	LEAD
U-DD084	ARP KUU	Short Decay	U-DD116	Charon Flute Lead	LEAD
U-DD085	303 ARP	Short Decay	U-DD117	Egeria Flute	Woodwind
U-DD086	ARP GRIAN	Short Decay	U-DD118	Flute Future	Woodwind
U-DD087	ARP ZUHAL	Short Decay	U-DD119	VOCAL FLUTE	Woodwind
U-DD088	ARP ORANOS	Short Decay	U-DD120	Bells SOP	Bells
U-DD089	DIAMONDS	Short Decay	U-DD121	Leda Piano	piano
U-DD090	LASER ARP	Short Decay	U-DD122	FX ATOOM	SFX
U-DD091	ARP ACTIVITY	Short Decay	U-DD123	Tree Key	SFX
U-DD092	ARP KEEP	Short Decay	U-DD124	Motor S P A C E	SFX
U-DD093	ARP TOY	Short Decay	U-DD125	Predator fx	SFX
U-DD094	DETONATOR SW1JS (-)	LEAD	U-DD126	Sound of Cristal	SFX
U-DD095	PIRANIA	LEAD	U-DD127	NATURA PAD	SFX

Multisamples :

00000	LASER	00046	evange
00001	LEAD SOP	00047	arp 1
00002	LEAD SOP 2	00048	arp 2
00003	303 ARP	00049	arp 3
00004	BASS SOP1	00050	arp 4
00005	PAD SOP 1 -L	00051	arp 5
00006	PAD SOP 1-R	00052	arp 6
00007	PAD TEXTURES-L	00053	arp 7-synth
00008	PAD TEXTURES-R	00054	arp 8
00009	TEXTURE HOME-L	00055	arp 9
00010	TEXTURE HOME-R	00056	arp 10
00011	SUPER DETUNE-L	00057	arp 11
00012	SUPER DETUNE-R	00058	granular
00013	BASS SOP 2-L	00059	BASS SOP5
00014	BASS SOP 2-R	00060	ANALOG LEAD
00015	BASS SOP 3	00061	DEEP BASS SOP 5
00016	SYNTH 1-L	00062	DEEP SYNTH LEAD
00017	SYNTH 1-R	00063	BASS SOP6
00018	DAL	00064	HYBRID SYNTH
00019	MOTION PAD-L	00065	LEAD SOP 3
00020	MOTION PAD-R	00066	MAGMA
00021	FILTER PAD-L	00067	WIFI
00022	FILTER PAD-R	00068	ZIPP LEAD
00024	SOP WRAP	00070	A indian
00025	Fear	00071	A oaaa
00026	futileFlanfe	00072	A ouu
00027	SOP LEAD mono	00073	A uuuu
00028	Mega Synth	00074	A voco 1
00029	noise	00075	A voco 2
00030	SQR	00076	mamMISTIC
00031	synth dance	00077	deep bEEp
00032	Suvox	00078	rezo
00033	DIGI Synth	00079	choir global
00034	fanta SYNTH	00080	pich choir
00035	glass hi	00081	A ze nie ma nas
00036	VOC 2	00082	eyes
00037	Retro	00083	poly 61
00038	comb motion	00084	short key
00039	TRISOP	00085	BASS SOP6
00040	sinus	00086	szuss tone
00041	miniKORG	00087	jua
00042	ATOM	00088	jup
00043	hit dirtu	00089	trance synth
00044	hel	00090	trance synth level 2
00045	MISTIC	00091	arp 13

New combis are installed in bank U-D. Combi List :

U-D000 LEDA PIANO SoP
U-D001 EGERIA SoP
U-D002 NAHEED SoP
U-D003 POP SYNTH SoP
U-D004 ISLAND BIT SoP
U-D005 POLY LIQUID SoP
U-D006 REA SoP
U-D007 TRINCULO SoP
U-D008 RELAX MELODY SoP
U-D009 SoP VOICES JS+Y
U-D010 LARISSA SoP
U-D011 SEQUENCE LIFE SoP
U-D012 LED OF ROCK SoP
U-D013 SYCORAX SoP
U-D014 GIOVE SoP
U-D015 ASTRAE SW1 SoP
U-D016 GALAXY SOUNDS SoP
U-D017 CONTEMPLATION SoP
U-D018 ARP WORLD SoP
U-D019 GOLDEN FIRE SoP
U-D020 SINGING WAVE SoP
U-D021 VARUN SoP
U-D022 SUKRA DANCE SoP
U-D023 AUREOLA SoP
U-D024 CHEMISTRY SoP
U-D025 ANGELS FLUTE MIX PAD SoP
U-D026 SHAI PUR MIX PAD SoP
U-D027 SECRET MIX PAD SoP
U-D028 FARAON MIX PAD SoP
U-D029 BLACK & WHITE MIX PAD SoP
U-D030 YELLOW LIGHT MIX PAD SoP
U-D031 WESTA MIX PAD SoP

The following instructions are copied from the Kronos Parameter Guide for your convenience:

Uninstall EXs

Optional EXs may be uninstalled to reclaim space on the internal disk(s). To do so:

1. Go to the Global P6: Options Info page.
2. In the list of Installed Options, select the EXs that you'd like to remove.
3. Select the Uninstall EXs command from the menu.

A dialog box will appear: Uninstall [EXs name and number]
Delete all of the option's EXs Samples and Multisamples?

4. Press OK to continue. Another dialog box will appear, showing that the uninstall is in progress. After the uninstall is complete, a third dialog box will appear: [EXs name and number] sample data deleted.

Related PCG, KSC etc. may remain; delete manually if desired. Only the EXs Multisamples and Drum Samples are removed from the disk. KSC and PCG files can be edited, and so they might contain your personal data; to avoid inadvertently affecting your data, these files are left untouched.

5. Press OK to continue.
6. If you like, delete the related PCG and KSC files manually in Disk mode.